


Position of Parts in Engine Compartment <RHD>




- * 1:LED Headlight
- * 2:Halogen Headlight
- * 3:Halogen Fog Light
- * 4:LED Fog Light



Position of Parts in Engine Compartment <RHD>

- A 36 Rear Washer Motor & Pump Assembly
- A 37 Level Warning Switch Assembly
- A 38 Headlight Assembly RH
- A 40 Headlight Assembly RH
- A 41 Headlight Assembly RH
- A 42 Headlight Cleaner Motor and Pump Assembly
- A 43 Cleaner Control Relay
- A 44 Front Airbag Sensor RH
- A 45 Engine Hood Courtesy Switch
- A 59 Front Wiper Deicer (Windshield Glass)
- A 60 ECM
- A 61 Skid Control ECU with Actuator Assembly
- A 62 Inverter Assembly with Converter
- A 73 Headlight Assembly LH
- A 75 Headlight Assembly RH
- A 76 Headlight Assembly LH
- A 77 Headlight Assembly RH
- A 79 Front Fog Light Assembly LH
- A 80 Front Fog Light Assembly RH
- A 81 Water Pump Assembly with Motor

Position of Parts in Engine Compartment <RHD>



Position of Parts in Engine Compartment <RHD>

