


Position of Parts in Engine Compartment <RHD 2AR-FSE>

* 1: Before Oct. 2015 Production
 * 2: From Oct. 2015 Production

















Position of Parts in Engine Compartment <RHD 2AR-FSE>


















- A 9 Windshield Wiper Motor Assembly
- A 10 Wireless Door Lock Buzzer
- A 11 Front Tire Pressure Monitor Initiator
- A 12 Brake Actuator Assembly
- A 14 Skid Control ECU Assembly
- A 15 Skid Control ECU Assembly
- A 16 Skid Control ECU Assembly
- A 17 Front Absorber Control Actuator LH
- A 18 Front Airbag Sensor LH
- A 22 Level Warning Switch Assembly
- A 23 Windshield Washer Motor and Pump Assembly
- A 24 Headlight Cleaner Control Relay
- A 25 Headlight Cleaner Motor and Pump Assembly
- A 26 Inverter Water Pump Assembly
- A 28 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
- A 29 Power Steering ECU Assembly
- A 42 Front Absorber Control Actuator RH
- A 43 Security Horn Assembly
- A 45 Front Airbag Sensor RH
- A 46 Engine Water Pump Assembly
- A 50 Junction Connector
- A 53 Junction Connector
- A 56 Junction Connector
- A 58 Junction Connector
- A 59 Junction Connector
- A 69 Junction Connector
- A 70 Front Wiper Deicer (Windshield Glass)
- A 74 Inverter with Converter Assembly
- A 75 Inverter with Converter Assembly
- A 79 ECM

- B 1 Front Fog Light Assembly RH
- B 2 Headlight Assembly RH
- B 3 No. 2 Wiring Harness Condenser Assembly
- B 4 Cooling Fan ECU
- B 5 Headlight Assembly LH
- B 6 Front Fog Light Assembly LH
- B 7 A/C Pressure Sensor (Liquid Tube Sub-Assembly)
- B 8 Ambient Temperature Sensor (Thermistor Assembly)
- B 9 Low Pitched Horn Assembly
- B 10 Engine Hood Courtesy Switch
- B 11 Swing Grille Actuator Assembly
- B 12 Millimeter Wave Radar Sensor Assembly
- B 13 High Pitched Horn Assembly
- B 14 Smog Ventilation Sensor
- B 15 Headlight Light Control ECU Sub-Assembly RH
- B 16 Headlight Light Control ECU Sub-Assembly LH
- B 17 Millimeter Wave Radar Sensor Assembly














Position of Parts in Engine Compartment <RHD 2AR-FSE>



Position of Parts in Engine Compartment <RHD 2AR-FSE>




Position of Parts in Engine Compartment <RHD 2AR-FSE>



Position of Parts in Engine Compartment <RHD 2AR-FSE>

B 16
Gray



B 17
Black

