


Position of Parts in Engine Compartment <LHD 2GR-FXE>




**Position of Parts in Engine Compartment <LHD 2GR-FXE>**

---

- V 1 Compressor with Motor Assembly
- V 2 Inverter with Converter Assembly
- V 3 Inverter with Converter Assembly
  
- h 1 Solenoid Valve Assembly
  
- o 1 Front Speed Sensor RH
- o 2 Front Speed Sensor LH
  
- u 1 Inverter with Converter Assembly
- u 2 Hybrid Vehicle Transmission Assembly
  
- v 1 Inverter with Converter Assembly
- v 2 Hybrid Vehicle Transmission Assembly
  
- z 6 Cooling Fan ECU , Cooling Fan Motor
- z 7 Cooling Fan ECU , No. 2 Cooling Fan Motor
- z 19 Oil Pump Motor Controller , Oil Pump with Motor Assembly
- z 20 Oil Pump Motor Controller , Oil Pump with Motor Assembly


Position of Parts in Engine Compartment <LHD 2GR-FXE>



Position of Parts in Engine Compartment <LHD 2GR-FXE>

---

z 19  
White



z 20  
Black

