


Position of Parts in Body <LHD>



























Position of Parts in Body <LHD>

---

- T 6 Front Door Courtesy Light Switch Assembly RH
- T 7 Rear Airbag Sensor RH
- T 8 Front Seat Outer Belt Assembly RH
- T 9 Front Seat Outer Belt Assembly RH
- T 10 Front Seat Outer Belt Assembly RH
- T 15 Rear Seat Inner Belt with Center Assembly RH
- T 16 No. 2 Fuel Sender Gage Assembly
- T 17 Rear Side Airbag Squib Circuit RH
- T 20 Side Airbag Sensor Assembly RH
- T 21 Rear Door Courtesy Light Switch Assembly RH
- T 22 Curtain Shield Airbag Assembly RH
- T 23 Rear Window Defogger (Back Window Glass)
- T 24 Rear No. 3 Speaker Assembly
- T 25 Rear Header Speaker Assembly RH
- T 26 Rear Seat 3 Point Type Belt Assembly Outer RH
- T 27 Rear Seat 3 Point Type Belt Assembly Outer RH
- T 29 Rear Absorber Control Actuator RH
- T 30 Rear Speed Sensor RH
- T 31 Rear Acceleration Sensor RH
- T 32 Tire Pressure Warning ECU and Receiver (Door Control and Tire Pressure Monitoring System Receiver Assembly)
- T 33 Door Control Receiver Assembly
- T 34 No. 1 Night View ECU
- T 36 Theft Warning Siren Assembly
- T 37 No. 3 Indoor Electrical Key Antenna Assembly
- T 38 Rear Electrical Key Antenna
- T 39 Blind Spot Monitor Sensor RH
- T 40 Stereo Component Amplifier Assembly
- T 44 Junction Connector
- T 45 Junction Connector
- T 46 Junction Connector
- T 47 Junction Terminal
- T 48 Junction Terminal
- T 49 Stereo Component Amplifier Assembly
- T 50 No. 1 Night View ECU
- T 51 Tire Pressure Warning ECU and Receiver (Door Control and Tire Pressure Monitoring System Receiver Assembly)
- T 52 Amplifier Antenna Assembly
- T 53 Blind Spot Monitor Sensor RH
- T 55 Vehicle Approaching Speaker Controller

Position of Parts in Body <LHD>



Position of Parts in Body <LHD>

